

Function	COMMAND	Value
Media	BRMediaType=Plain	Plain Paper
	BRMediaType=Inkjet	Inkjet Paper
	BRMediaType=BrotherGlossyR	Brother BP71 Photo Paper
	BRMediaType=BrotherGlossy	Brother BP61 Photo Paper
	BRMediaType=BrotherBP60Matte	Brother BP60 Matte Paper
	BRMediaType=Glossy	Other Photo Paper
	BRColorMediaType=Transparencies	Transparencies
	BRMediaType=PrintableDisc	Printable Disc
	BRMediaType=GlossyPrintableDisc	Glossy Printable Disc
	BRColorMediaType=HagakiAtena	HagakiAtena
	BRColorMediaType=HagakiUra	HagakiUra
Resolution	BRResolution=PlainFast	Plain Fast
	BRResolution=PlainNormal	Plain Normal
	BRResolution=DiscNormal	Disc Normal
	BRResolution=DiscSlow	Slow Drying
	BRResolution=Fast	Fast
	BRResolution=Normal	Normal
	BRResolution=Photo	Photo
	BRResolution=High	High
BRResolution=Best	Best	
Bi-Dir Printing	BRBiDir=OFF	Off
	BRBiDir=ON	On
	PageSize=A4	A4
	PageSize=BrA4_B	A4 (Borderless)
	PageSize=Letter	Letter
	PageSize=BrLetter_B	US Letter (Borderless)
	PageSize=Legal	Legal
	PageSize=Executive	Executive
	PageSize=B5	JIS B5
	PageSize=A5	A5
	PageSize=A6	A6
	PageSize=BrA6_B	A6 (Borderless)
	PageSize=BrPostC4x6_S	4 x 6 in
	PageSize=BrPostC4x6_B	4 x 6 in (Borderless)
	PageSize=BrIndexC5x8_S	5 x 8 in
	PageSize=BrIndexC5x8_B	5 x 8 in (Borderless)
	PageSize=BrPhotoL_S	3.5 x 5 in
	PageSize=BrPhotoL_B	3.5 x 5 in (Borderless)
	PageSize=BrPhoto2L_S	5 x 7 in
	PageSize=BrPhoto2L_B	5 x 7 in (Borderless)
	PageSize=Postcard	Postcard 1
	PageSize=BrHagaki_B	Postcard 1 (Borderless)
	PageSize=DoublePostcardRotated	Postcard 2 (Double)
	PageSize=EnvC5	C5 Envelope
	PageSize=EnvDL	DL Envelope
	PageSize=Env10	Com-10
	PageSize=EnvMonarch	Monarch
	PageSize=EnvYou4	Y4 Envelope
PageSize=Br12cmDisc	12 cm Disc	

Paper Thickness	BRColorPaperThick=Regular	Regular
	BRColorPaperThick=Thick	Thick
	BRColorPaperThick=Env	Envelope
Color Or Mono	BRMonoColor=Color	Color
	BRMonoColor=Mono	Grayscale
Color Matching	BRColorMatching=Natural	Natural
	BRColorMatching=Vivid	Vivid
	BRColorMatching=None	None
jpeg print mode	BRJpeg=Recommended	Recommended Setting
	BRJpeg=QualityPrior	Improved Print Quality
	BRJpeg=SpeedPrior	Improved Print Speed
Half Tone	BRHalfTonePattern=Diffusion	Diffusion
	BRHalfTonePattern=Dither	Dither
Color Enhance	BRColorEnhancement=OFF	Off
	BRColorEnhancement=ON	On
Slow Dry	BRSlowDrying=OFF	Off
	BRSlowDrying=ON	On
MirrorPrint	BrMirror=OFF	Off
	BrMirror=ON	On
reverse order	BRReverse=OFF	Off
	BRReverse=ON	On
Duplex	BRDuplex=DuplexTumble	Short-Edge Binding
	BRDuplex=DuplexNoTumble	Long-Edge Binding
	BRDuplex=None	Off
Advanced Duplex Settings	BRDuplexMode=Normal	Normal
	BRDuplexMode=Duplex1	Duplex 1 (Slower print speed)
	BRDuplexMode=Duplex2	Duplex 2 (Slower print speed & less ink)
Brightness	BRBrightness=xx	xx = -20 乃至 +20
Contrast	BRContrast=xx	xx = -20 乃至 +20
Red Key	BRRed=xx	xx = -20 乃至 +20
Green Key	BRGreen=xx	xx = -20 乃至 +20
Blue Key	BRBlue=-xx	xx = -20 乃至 +20